

(1) 50mm PlaySoft wearing course

(2) PlaySoft Cushion layer varies in depth

Concrete or Asphalt

(3) Diluted prime for a light tack

(4) Apply primer to perimeter edge 9" wide and extend surface course over same

3"-9"

- 1) Surface course shall measure minimum 50mm
- 2) Cushion layer varies in thickness and is dependent on Critical Height of Structure
- 3) Apply a light diluted primer to concrete or asphalt
- 4) Apply binder 3"-9" wide around entire perimeter and extend compacted surface to 3"-9" width.



www.ure-techsurfaces.com • info@ure-techsurfaces.com